

# RTS

## Introduction

Tydom 3.0 controls RTS shutters/blinds using the RFXCOM rfxtrx433e module:

http://www.rfxcom.com/epages/78165469.sf/en\_GB/?ViewObjectPath=%2FShops%2F78165469%2FProducts%2F14103

#### Connector

From Config Studio, create the connector located in RTS/ RFXCOM/RFXtrx433E.

In properties, select the module in port COM:

Connectors Manager	۲
USB RFXtrx433E	Label :
	RFXtrx433E
RFXCOM RFXCOM Interface : RFXtrx433E	Short label :
	Description :
•••> = \ @	
	Properties :
	COM Port
	FT232R USB UART (A9049VJ7) 🕨 🕑

Save and start the connector.



## Devices

From Config Studio, open the 'Devices' tab.

You can create either a 'roller shutter' or a 'roller blind'.

Click on the pencil icon and select the RFXCOM connector.

Properties :		
ID ( 0-15 / 0-255 / 1-255)		
0	0	2
Unit code ( 0-4 )		
	1	
Pair	Unpair	Test

You now have to enter an ID and unit code.

The unit code 0 controls the shutters with a similar ID and the unit code falls between 1 and 4. This enables the creation of a device that will control all the shutters in a room at once.

By default Tydom 3.0 will generate a new one for each shutter.

The ID/unit code association must be unique for each shutter.

A generated ID is not automatically associated with the shutter.

You have to click on the 'Pair' button. A pop-up prompts you to associate the shutter.



To start the association, press the teach button for 3 seconds.

(The button is located at the back of your Somfy remote control).

You shutter should very briefly move down then up again.



#### Press OK.

If the association is successful, your shutter should again briefly move down then up again.

You can check by pressing the Test button.

If you have already configured the gateway via the RFXCOM software, you can now enter the IDs in the device. Note that deleting a device will not unpair the shutter. You have to click on 'Unpair' before deleting it.

#### Use

The RTS protocol can only control shutters/blinds. There is therefore no state feedback on the shutter's position. In Tydom 3.0 interfaces, it will be in the form of an Raise/Lower/Stop button

